476.00 mm

68.00 mm

90.00 mm

正面1

WIRELESS 2D BARCODE SCANNER

—— make scanning easy

正面2

Parts Instruction

正面3

Receiver Pairing

Scan the "Receiver Pairing Code" on the base

Factory Default: barcode scanner paired with base

正面4

Indicator Description



Indicator Description

Indicator Type	Details Description
Battery	Four bars , charging flash
Wireless status	Bluetooth/2.4G connection
Pairing	Bluetooth/2.4G quick flash
Scanner ring light	One flash for one successful scanning
Base ring light	One flash for one successful data transferring Slow flash for pairing mode

正面5

Product Introduction

This is the simple user's manual, for detailed manual, please download from our website or contact the supplier. (With * is the Default Setting)

Factory Default

If scanner cannot be used normally due to an error setting, try to scan the "Factory Default" code above.

Buzzer Description

Voice Type	Details Description
One medium long high voice	Successful scanning or pairing
Three continuous short voice	Alarm prompt

正面6

Wireless Transmission Mode

*2.4G

Bluetooth

Bluetooth BLE

Bluetooth SPP

正面7

Data Transfer Mode

* Immediate mode

Inventory mode

Clear all data

Upload data

Upload all data

90.00 mm

背面7

V9.0.1EN

背面6

Interface Type

* USB-HID

USB Virtual Com Port
(Driver is needed for USB Virtual Com Port)

背面5

Sleep Time

Sleep Immediately

* 1 min

5 min

30 min

背面4

Language

*USA

France

Germany

Turkey Q

Poland

背面3

Language

Brazil

Italy

Spain

Universal language

*For more languages setting, please refer to the full manual.

背面2

Terminator

NONE

*CR

LF

TAB

CR/LF

背面1

Receiver Pairing

2.4G Receiver Pairing

Scanning the "Receiver Pairing" code, scanner will enter the automatic pairing mode for 1 minute, then re-insert the receiver to the host. There will be a sound heard when pairing successfully.

Bluetooth HID Pairing

Scan the "Bluetooth HID Pairing" barcode, the scanner is ready to be connected by other bluetooth devices.

Scanner Version Information